## How Uniview (OEM) NVR to connect Camera and Camera setting

- 1. Open explorer and enter NVR IP address on Desktop/Laptop/Mobile
- 2. Log into the NVR, go to below interface and access the camera directly.

## Desktop/Laptop



## Mobile

		Li	ve Vie	w 🖽	Playback	🄹 s	etup				
Client	*	Cam	era		Advance	d					
System	~										
Camera	•	Auto	Switc	to H.265	0 On (	On Off Note: Effective when first connected					
Camera		Auto Switch to Smart Encod			oding Off	ing Off O Note: Effective when first connected					
Encoding		De	feach	Marth	Auto Count	Passa	h Casmant				
OSD		HO	rresn	Modity	Auto Search	Searc	n segment				
Image		0	No.	Camera ID	Address	Port	Remote Camera ID	Protocol	Status	Vendor	
Schedule			1	Di	1/2.16.0.10	80	1	ONVIE		ONVIF_ICAMER	
Motion			2	02	172.10.0.3	80	1	ONVIE	CER CER	ONVIE ICAMER	
Video Loss			4	D4	172.10.0.4	80	1	ONVIE	COM .	ONVIE ICAMER	
Tampering			5	D5	172.16.0.6	80	1	ONVIE	1004	ONVIF_ICAMER/	
Privacy Mask			6	D6	172.16.0.7	80	1	ONVIF	EDI	ONVIF_ICAMER/	
Human Body Detection			7	D7	172.16.0.8	80	1	Private	EN		
/CA	*		8	D8	172.16.0.9	80	1	Private	121	4	
lard Disk	~						-				
Marm	~										
lert	¥			•	- 1 C					100	
letwork	¥			LIR	nd.		Acc	0	C	c "	
Platform	V				IU			С.	5.		
Jser	~										
									1		



## m 🊺 Configuration Custom Title Image art LED light Co Light I 128 128 128 Light off LED Cor Light or iôp PTZ )<sup>11</sup> Event 5 Storage Ford ed ar 📑 System Reset Defaults i) Inforr rizon Flip ogging Day Shu **IRCut Setting** IRCut Mode Keep Color

3. Then log into the camera, go to below interface and set the camera Horizon flip, vertical flip, etc.